

CONTENTS

Introduction	23
Accuracy and precautions for use	23
Water resistance	24
"1000 Hours Control" test	27
Technical specifications	28
Movement	28
Functions and displays	29
Use	32
International Guarantee	39
Limited Warranty (United States of America and Canada)	43
Guarantee for Australia	47
Customer Service	52



- 1 Moon phases
- 2 Minute hand
- 3 Aperture indicating the security zone
- 4 Crown
- 5 Date
- 6 Month
- 7 Year
- 8 Corrector
- 9 Second hand
- 10 Day
- 11 Hour hand

INTRODUCTION

We would like to thank you for the confidence you have placed in Jaeger-LeCoultre. Our Maison has applied all its expertise and exacting standards to the creation of this model.

We invite you to consult the operating instructions and hope your Jaeger-LeCoultre timepiece brings you great joy.

ACCURACY AND PRECAUTIONS FOR USE


MANUALLY-WOUND OR AUTOMATIC MECHANICAL WATCHES

The accuracy of watch models with mechanical movements is determined by the balance wheel. This oscillates at a rate of 28,800 vibrations per hour. Despite all the care that the master watchmakers of the Jaeger-LeCoultre Manufacture have lavished on building and assembling your

watch, its accuracy is subject to the influence of gravity, magnetic fields, accidental impacts, and the ageing of the oils. The accuracy of a watch is measured by its regularity of rate in various positions.

Your individual activities could be the cause of slight irregularities in the working of your timepiece. If you observe a discrepancy in the way your watch runs, we advise you to entrust it to an authorised Jaeger-LeCoultre retailer who will make the necessary adjustments. Watches with mechanical movements must not be used for sports involving significant risk of impact or abrupt actions, such as golf or tennis.

WATER RESISTANCE

Your Jaeger-LeCoultre watch is water-resistant to 5 bar. Its water resistance can be identified by the  symbol and/or the engraving: “5 bar” on the caseback. This means that your model has been tested at an overpressure of 5 bar, corre-

sponding to an immersion pressure of 50 metres (1 bar = ± 10 metres).

In accordance with the ISO 22810/NIHS 92-20 standard, in order to guarantee the durability of the watch's characteristics over time, and as water resistance may be affected by certain activities, it is recommended that you:

- have the watch's water resistance checked by an authorised Jaeger-LeCoultre retailer at least once every two years. It is essential to have such a check carried out each time your watch is opened, and before any period in which it is liable to undergo prolonged and/or regular immersions.
- check when making the purchase that the bracelet is suitable for the intended use.
- avoid subjecting the watch to excessively abrupt temperature changes.
- protect the watch from being dropped or suffering other accidental impacts, and have the water resistance checked after any severe impact.


- avoid using the controls, push-piece, or time-setting crown while under water, or outside the water, if the watch is not yet dry after immersion.
- restore the time-setting crown and the push-pieces to their normal positions, (or where applicable, close the compression keys) after every manipulation.
- rinse the watch with fresh water after use in sea water.

You may use your watch while swimming as long as you do not exceed the immersion pressure and do not engage in any water sports that could cause impacts. This watch is not a piece of diving equipment and should not be used as such. Also, note that leather straps are not suited for aquatic activities.

“1000 HOURS CONTROL” TEST

The Jaeger-LeCoultre Manufacture pays close attention to the quality and to the final checks of its watches.

The 1000 Hours Control is a series of internal qualification tests for each of the models in our collection, as well as internal tests on the production of your watch, which go beyond official timing tests. These tests include checks of the movement before and after being cased up in the watch and cover the whole watch once it has been assembled, in the conditions closest to daily wear.


The “1000 Hours Control” legend, or the “” seal engraved on the back of the watch certifies that each of the models from our collection has successfully undergone all of the qualification tests, and that your watch has successfully undergone all of the production tests. These ensure regularity of rate, resistance to variations

in temperature and atmospheric pressure, ability to withstand shocks and magnetic fields, as well as water resistance.

TECHNICAL SPECIFICATIONS

- Automatic mechanical movement, Jaeger-LeCoultre Calibre 868.
- 28,800 vibrations/hour.
- Power reserve: approximately 38 hours.

MOVEMENT



Jaeger-LeCoultre Calibre 868.

FUNCTIONS AND DISPLAYS

The watch offers the following functions:

- Hours
- Minutes
- Seconds
- Date
- Day
- Month
- Year
- Moon phases
- Perpetual Calendar
- Security zone indication

The perpetual calendar has a mechanism that takes into account the length of the current month (28, 30 or 31 days), and counts a 29th February every leap year. The date, day of the week, month, year, and moon phase are therefore indicated

mechanically, without the slightest need for readjustment until 1 March 2100.

All these are interlinked by the ingenious mechanism of a genuine, entirely mechanical programme: merely changing the initial date thus effects the appropriate changes in all other functions.

Our time measurement is based on the Gregorian calendar, i.e. a year of 365 days, 5 hours, 48 minutes, and 46 seconds, or in decimals, 365.242192 days. In practice, the yearly excess of just less than a quarter (0.242192) of a day is corrected by the 29th February in leap years. The few missing decimals are then compensated for every 100 years, by excluding 29th February.

For the sake of greater precision, this exclusion does not take place when the number of centuries is divisible by 4. Such is the case for the years 2000 and 2400

(centuries divisible by 4), which are both regular leap years. It is therefore only in the year 2100 that the programming of your perpetual calendar will need to be corrected. Until that date, your watch will count days, months, and decades. On 1 March 2100, the calendar will indicate Monday, 29th February, whereas in fact it will be Monday, 1st March. A watchmaker will then have to set your watch to the correct date, together with the moon phase, which varies by one day in every 122 years.

The Master Ultra Thin Perpetual's crown allows you to:

- Wind the watch if it has not been worn for more than 38 hours.
- Set the desired time.

USE



WINDING

Your Master Ultra Thin Perpetual watch is equipped with a 38-hour power reserve, during which time it can operate without any additional winding.

Crown in position 0.

A few clockwise turns of the crown are enough to set the watch running. It will then automatically wind up when you wear it. Please note that the crown does

not lock during winding, even when the watch is fully wound.

SETTING THE HOURS AND MINUTES

Pull the crown out to position 1.

Move the hands clockwise until the desired time is displayed. When the hands are displaying times during the night between 8 p.m. and 4 a.m., with what is known as the security zone in red, you must never:

- Turn back the hour or minute hands.
- Perform a date correction.

When the operation is complete, push the crown back to position 0.

Special nature of the four-digit year indicator:

The year is indicated via four positions. The display of the year's first two digits (the century) is fixed. It consists of a small two-position plate, screwed onto the movement, which can indicate "20" or "21". The decade display consists of two dis-

cs which run through the positions from “00” to “99” according to the perpetual calendar mechanism. On 1 January 2100, the watch will therefore indicate the year 2000 (fixed “20” + “00”). We advise you to wait until 1 March 2100 before submitting your Master Ultra Thin Perpetual watch to an authorised watchmaker, so as to have the year plate set to position “21”, while the necessary adjustments are made to the date and the moon phase.

SIMULTANEOUS CALENDAR (DAY, DATE, MONTH, AND YEAR) AND MOON PHASE ADJUSTMENT

This operation is entirely controlled by a single corrector located at 8 o'clock, which can be operated via the corrector tool supplied with the watch. Each press of the tool moves the calendar one day forward. Therefore all that's needed is to set the initial calendar by pressing the push-piece until the corresponding date and month are displayed, to ensure that the day, date,

month, year, and moon phase programme run correctly thereafter.

We remind you that you should not:

- Perform this calendar correction between 8 p.m. and 4 a.m..
- Move the calendar forward beyond the current date. The movement is programmed mechanically and cannot be adjusted by moving the date backward. If the calendar is accidentally moved forward beyond the current date, you have two options:
 - Wait for the power-reserve to run out. The watch will stop.
 - Wait until the day of the inadvertently programmed date before winding the watch.

To set your Master Ultra Thin Perpetual watch, there is no need to know whether or not the year is a leap year, nor the current moon phase. Nor is it necessary to set the day of the week, because this data is automatically programmed in your watch.

ADJUSTING THE WATCH WHEN CHANGING TIME ZONES (OR WHEN SWITCHING FROM DAYLIGHT SAVING TIME TO WINTER TIME AND VICE VERSA)

Pull the crown out to position 1.

- If you are travelling towards the East, move the hour forward to display the new local time.
- If you are travelling towards the West, turn the hands back, but without ever going beyond 4 a.m., at which point the red security zone reappears in the aperture. If this situation arises, wait to make the correction until a time when this is possible.

ADJUSTING THE WATCH FOR A DATE CHANGE

Pull the crown out to position 1.

When changing date while travelling towards the West, such as going from America to Asia, you move on to the next day:

- Adjust your watch by moving the hands forward until you reach the following day and the local time.
- You can also use the corrector push-piece to move the date forward.

When changing date while travelling towards the East, you move back to the previous day:

In this case, however, the watch will indicate one day earlier.

This date display error can be corrected by twice turning the hands back by 12 hours each time, so as not to go back beyond the security zone (i.e. between 8 p.m. and 4 a.m.).

The correction is performed as follows:

- The first 12-hour windback is performed in the afternoon between 4 p.m. and 8 p.m. For example, if you perform this operation at 8 p.m., the day/night indication dial of your watch will show 8 a.m. instead of 8 p.m. after this first turn.

- The second 12-hour windback is performed the following morning between 4 a.m. and 10 a.m. For example, if you perform this operation at 8 a.m., your watch will once more display 8 a.m. (current time with the correct date).

The date indicator will once more be synchronised with the local date.

JAEGER-LECOULTRE WATCHES

In order to benefit from the International Guarantee and/or the Limited Warranty and/or the Manufacturer's Guarantee for Australia, Jaeger-LeCoultre products must be purchased exclusively from authorised Jaeger-LeCoultre retailers or from Jaeger-LeCoultre Boutiques. Maintenance and repair work must be entrusted to an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre. If these conditions are not met, the manufacturer's guarantee does not apply. Please contact Jaeger-LeCoultre to obtain the list of authorised Jaeger-LeCoultre retailers across the world.

INTERNATIONAL GUARANTEE


The International Guarantee applies to Jaeger-LeCoultre products sold or presented for guarantee repairs in all countries, except the United States of America and Canada (for these two countries, see the Limited Warranty) and Australia (for this country, refer to the Guarantee for Australia).

TERMS AND CONDITIONS OF THE JAEGER-LECOULTRE INTERNATIONAL GUARANTEE

Your Jaeger-LeCoultre watch is guaranteed to protect against all manufacturing defects for two years from the date of purchase, subject to the following conditions. Any part found by our technical services to be defective as a result of a manufacturing defect will, at the sole discretion of Jaeger-LeCoultre, be repaired or replaced free of charge. The Jaeger-LeCoultre In-

ternational Guarantee is valid only if the guarantee certificate enclosed with this booklet has been duly completed, dated, stamped, and signed by the authorised Jaeger-LeCoultre retailer or the Jaeger-LeCoultre Boutique, which sold you your watch.

The Jaeger-LeCoultre International Guarantee does not cover defects resulting from accidents, mishandling, or incorrect, abusive use (for example, knocks, dents, crushing, excessive temperatures, powerful magnetic fields), the use of or effect of using batteries other than those designated by Jaeger-LeCoultre, unauthorised alteration or repair, the consequences of normal wear and ageing of the watch, strap, or glass, the loss of water resistance after two years from the date of purchase, if your watch is water-resistant, or any defect resulting from contact with water, if your watch is not water-resistant.

Jaeger-LeCoultre water-resistant watches can be identified by the symbol  and/or

by “3, 5, 10, or 20 bar” (or another number depending on the model) engraved on the caseback. Their water resistance is guaranteed for two years from the date of purchase, provided that the glass, bezel, back, middle part, and crown have not been damaged. It is nevertheless essential to have the water resistance of your watch checked at least once every two years, and in any event, prior to any period of intensive use, either by an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre (for further information please see your User Manual).

For quartz watches, this guarantee does not cover the battery life.

As a consumer, you may have legal rights under applicable national legislation governing the sale of consumer goods; those rights are not affected by this guarantee.

LIMITED WARRANTY (UNITED STATES OF AMERICA AND CANADA)


The following Limited Warranty applies to Jaeger-LeCoultre products sold or presented for warranty repairs in the United States of America and Canada only.

TERMS AND CONDITIONS OF THE JAEGER-LECOULTRE LIMITED WARRANTY

Your Jaeger-LeCoultre watch is guaranteed against all manufacturing defects for two years from the date of purchase, subject to the following conditions. Any part found by our technical services to be defective as a result of a manufacturing defect will, at the sole discretion of Jaeger-LeCoultre, be repaired or replaced free of charge. The Jaeger-LeCoultre Limited Warranty is valid only if the warranty certificate enclosed with this booklet has been duly

completed, dated, stamped, and signed by the authorised Jaeger-LeCoultre retailer or the Jaeger-LeCoultre Boutique, which sold you your watch.

This Jaeger-LeCoultre Limited Warranty does not cover defects resulting from accidents, mishandling, or incorrect, abusive use (for example, knocks, dents, crushing, excessive temperatures, powerful magnetic fields), the use of or effect of using batteries other than those designated by Jaeger-LeCoultre, unauthorised alteration or repair, the consequences of normal wear and ageing of the watch, strap, or glass, the loss of water resistance after two years from the date of purchase, if your watch is water-resistant, or any defect resulting from contact with water, if your watch is not water-resistant.

Jaeger-LeCoultre water-resistant watches can be identified by the symbol  and/or by “3, 5, 10, or 20 bar” (or another number depending on the model) engraved on the caseback. Their water resist-

ance is guaranteed for two years from the date of purchase, provided that the glass, bezel, back, middle part, and crown have not been damaged. It is nevertheless essential to have the water resistance of your watch checked at least once every two years, and in any event, prior to any period of intensive use, either by an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre (for further information please see your User Manual).

For quartz watches, this guarantee does not cover the battery life.

Except insofar as prohibited by applicable law, this Limited Warranty shall be the exclusive manufacturer warranty. Neither this Limited Warranty nor any other warranties, whether expressed or implied, including, but not limited to, any implied warranty of merchantability or of fitness for any particular purpose, shall extend

beyond the period of two years from the date of purchase.

The liability of Jaeger-LeCoultre is limited solely and exclusively to repair or replacement under the terms and conditions stated herein. Jaeger-LeCoultre shall not be liable, by virtue of this Limited Warranty or otherwise, for any loss or damage arising out of the use of or inability to use this watch nor for any incidental or consequential damages relating in any way to this watch.

Some States, Provinces, and Territories do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This Limited Warranty grants you specific legal rights, in addition to which you may have other legal rights that vary from one Country, State, Province, or Territory to another.

GUARANTEE FOR AUSTRALIA

This Guarantee for Australia applies to Jaeger-LeCoultre products purchased or presented for guarantee repairs in Australia only.

TERMS AND CONDITIONS OF THE JAEGER-LECOULTRE GUARANTEE FOR AUSTRALIA


Mandatory Statutory Rights. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced, if goods fail to be of acceptable quality and the failure does not amount to a major failure.

This Jaeger-LeCoultre Guarantee gives you additional rights and remedies under the Australian Consumer Law and

any other laws in relation to the goods. Every Jaeger-LeCoultre product is made and tested to meet the Jaeger-LeCoultre quality standards. Nevertheless, should your Jaeger-LeCoultre product prove defective, please contact the Jaeger-LeCoultre retailer or Jaeger-LeCoultre Boutique indicated on your guarantee certificate; only authorised Jaeger-LeCoultre retailers or Jaeger-LeCoultre Boutiques are entitled to provide a guarantee service as defined in this Jaeger-LeCoultre Guarantee. In order to benefit from this guarantee, you will be required to present this Jaeger-LeCoultre guarantee certificate duly completed, dated, stamped, and signed by an authorised Jaeger-LeCoultre retailer or a Jaeger-LeCoultre Boutique.

This Jaeger-LeCoultre Guarantee covers defects of materials or workmanship of your Jaeger-LeCoultre product. Subject to your Mandatory Statutory Rights under the Australian Consumer Law,

Jaeger-LeCoultre will remedy these identified defects free of charge for up to two (2) years from the date of purchase. Thereafter, Jaeger-LeCoultre will repair any defective product or part subject to a service charge. The Jaeger-LeCoultre Guarantee does not cover defects and damage caused by accident, improper use (including knocks, dents, crushing, etc.), normal wear and tear, alteration, dismantling, repair by persons other than authorised Jaeger-LeCoultre repair specialists, the use of components other than those recommended by Jaeger-LeCoultre, watches with the serial number removed, the strap or glass altered, the loss of water resistance after two years from the date of purchase, if your watch is water-resistant, and any defect resulting from the contact with water, if your watch is not water-resistant.

Jaeger-LeCoultre water-resistant watches can be identified by the  symbol and/or by “3, 5, 10, or 20 bar” (or another number depending on the model) en-

graved on the caseback. Their water resistance is guaranteed for two years from the date of purchase, provided that the glass, bezel, back, middle part, and crown have not been damaged. It is essential to have the water resistance checked by an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre at least every two years, and in any event, prior to any period of intensive use. Please refer to the operating instructions for further details. For quartz watches, this guarantee does not cover the battery life.

Subject to your Mandatory Statutory Rights under the Australian Consumer Law, if you make a claim under this Jaeger-LeCoultre Guarantee (instead of your Mandatory Statutory Rights) you may be responsible for transportation costs, including but not limited to postage, insurance and packing materials.

In Australia, a claim under the Jaeger-LeCoultre Guarantee may be sent to Richemont Australia Pty Ltd, provider of the guarantee service, at the address below or as specified above:

Richemont Australia Pty Ltd

PO Box 4780

Sydney, NSW 2001

Tel: +1 800 71 0665

Email: client.relations.asia@jaeger-lecoultre.com

CUSTOMER SERVICE

A Jaeger-LeCoultre timepiece is a high-precision instrument that operates 24 hours a day, or 8,760 hours a year. Therefore, it is essential to have it serviced regularly in order to guarantee its good working order and its durability. If significant variations occur in the settings, it may be necessary to have the movement serviced. It is also necessary to have the water resistance of the watch checked once every two years, or prior to any period during which it will be subjected to prolonged and/or regular immersion.

Maintenance and repair work must be entrusted to an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre. The list of our points of sale and service centres is available on our website: www.jaeger-lecoultre.com. You will also find this information at the end of this

document, under the heading “Where to entrust my timepiece for maintenance?”

Our authorised Service Centres are staffed by watchmakers trained at the Jaeger-LeCoultre Manufacture, and have the workshops, tools, and parts required for the repair and maintenance of Jaeger-LeCoultre watches and clocks.

In certain cases, especially for operations requiring special tools and parts, the Service Centres will send your watch to the Jaeger-LeCoultre Manufacture in Switzerland to have the necessary work carried out.