

CONTENTS

Introduction	21
Accuracy and precautions for use	21
Water resistance	22
"1000 Hours Control" test	25
Care instructions for leather straps	26
Technical specifications	27
Movement	27
Use	28
International Guarantee	32
Limited Warranty (United States of America and Canada)	36
Guarantee for Australia	40
Customer Service	45



- 1** Month
- 2** Corrector A: Setting the month
- 3** Crown: Setting the time
- 4** Minute hand
- 5** Corrector B: Setting the date
- 6** Seconds hand
- 7** Moon Phases
- 8** Corrector C: Setting the Moon phases
- 9** Hour hand
- 10** Day
- 11** Date

INTRODUCTION

We would like to thank you for the confidence you have placed in Jaeger-LeCoultre. Our Maison has applied all its expertise and exacting standards to the creation of this model.

We invite you to consult the operating instructions and hope your Jaeger-LeCoultre timepiece brings you great joy.

ACCURACY AND PRECAUTIONS FOR USE


MANUALLY-WOUND OR AUTOMATIC MECHANICAL WATCHES

The accuracy of watch models with mechanical movements is determined by the balance wheel. This oscillates at a rate of 28,800 vibrations per hour. Despite all the care that the master watchmakers of the Jaeger-LeCoultre Manufacture have lavished on building and assembling your

watch, its accuracy is subject to the influence of gravity, magnetic fields, accidental impacts, and the ageing of the oils. The accuracy of a watch is measured by its regularity of rate in various positions.

Your individual activities could be the cause of slight irregularities in the working of your timepiece. If you observe a discrepancy in the way your watch runs, we advise you to entrust it to an authorised Jaeger-LeCoultre retailer who will make the necessary adjustments. Watches with mechanical movements must not be used for sports involving significant risk of impact or abrupt actions, such as golf or tennis.

WATER RESISTANCE

Your Jaeger-LeCoultre watch is water-resistant to 5 bar. Its water resistance can be identified by the  symbol and/or the engraving: “5 bar” on the caseback. This means that your model has been tested at an overpressure of 5 bar, corre-

sponding to an immersion pressure of 50 metres (1 bar = ± 10 metres).

In accordance with the ISO 22810/NIHS 92-20 standard, in order to guarantee the durability of the watch's characteristics over time, and as water resistance may be affected by certain activities, it is recommended that you:

- have the watch's water resistance checked by an authorised Jaeger-LeCoultre retailer at least once every two years. It is essential to have such a check carried out each time your watch is opened, and before any period in which it is liable to undergo prolonged and/or regular immersions.
- check when making the purchase that the bracelet is suitable for the intended use.
- avoid subjecting the watch to excessively abrupt temperature changes.
- protect the watch from being dropped or suffering other accidental impacts, and have the water resistance checked after any severe impact.


- avoid using the controls, push-piece, or time-setting crown while under water, or outside the water, if the watch is not yet dry after immersion.
- restore the time-setting crown and the push-pieces to their normal positions, (or where applicable, close the compression keys) after every manipulation.
- rinse the watch with fresh water after use in sea water.

You may use your watch while swimming as long as you do not exceed the immersion pressure and do not engage in any water sports that could cause impacts. This watch is not a piece of diving equipment and should not be used as such. Also, note that leather straps are not suited for aquatic activities.

“1000 HOURS CONTROL” TEST

The Jaeger-LeCoultre Manufacture pays close attention to the quality and to the final checks of its watches.

The 1000 Hours Control is a series of internal qualification tests for each of the models in our collection, as well as internal tests on the production of your watch, which go beyond official timing tests. These tests include checks of the movement before and after being cased up in the watch and cover the whole watch once it has been assembled, in the conditions closest to daily wear.

The “1000 Hours Control” legend, or the “” seal engraved on the back of the watch certifies that each of the models from our collection has successfully undergone all of the qualification tests, and that your watch has successfully undergone all of the production tests. These ensure regularity of rate, resistance to variations

in temperature and atmospheric pressure, ability to withstand shocks and magnetic fields, as well as water resistance.

CARE INSTRUCTIONS FOR LEATHER STRAPS

1. Keep the leather strap in a dry place
2. Avoid contact with water, cosmetics, perfumes, alcohol and oily materials
3. To prevent leather from discolouring, avoid wearing the watch:
 - in a highly humid environment
 - during a sporting activity: sweat damages the leather
 - in prolonged exposure to sunlight
4. Wipe with a dry and soft fabric. Do not dry in direct sunlight or near heat sources

TECHNICAL SPECIFICATIONS

- Automatic mechanical movement, Jaeger-LeCoultre Calibre 866AA.
- 28,800 vibrations/hour.
- Power-reserve: approximately 70 hours.

MOVEMENT



Jaeger-LeCoultre Calibre 866AA

USE



STARTING THE WATCH

Leave the crown in position 0.

A few clockwise turns of the crown are enough to start your watch. It will then automatically wind up when you wear it. Please note that the crown does not lock when winding, even when the watch is fully wound.

SETTING THE DAY AND TIME

Pull the crown out to position 1.

The movement is then locked (“stop seconds” function). For an accurate time setting in seconds, stop the seconds hand at 12 o’clock.

Turn the hands clockwise through 12 midnight, the time when the day of the week disc moves forward by one day. Having reached the desired day of the week and set the exact time, push the crown back to position 0.

When setting your watch during the afternoon, you must first turn the hands through 12 noon.

SETTING THE DATE, MONTH, AND MOON PHASE

The date, month, and moon-phase adjustments can be carried out by pressing the correctors A, B, and C using the stylus provided with your watch.

SETTING THE DATE

Press corrector B at 4 o’clock.

Each press moves the date hand one day forward.

For months with less than 31 days, repeat this process to reach the 1st of the following month. The date scale, logically numbered from 1 to 31, is written around the dial. The hand with the JL symbol on the end indicates today's date. The date scale stops on the 15th day of every month on one side of the dial with the moon phase, and starts the 16th day of every month on the other side. On the 15th day of every month, the hand passes from the 15th to the 16th at a higher speed than usual – in a little less than 1 hour. Please note that this date mechanism also leads to a change in the following indications: day, month and moon phase. This change is performed in less than 3 hours.

SETTING THE MONTH

Press corrector A at 2 o'clock.

Each press moves the disc one month forward.

SETTING THE MOON PHASE

Press corrector C at 8 o'clock.

Each press moves the disc one day forward.

To ensure correct adjustment, calculate the number of days that have elapsed since the last full moon using the calendar at the end of this user manual. Centre the moon in the aperture, then move the disc forwards according to the number of days that have elapsed since the last full moon.

Note: date or moon phase corrections should not be performed between 10 p.m. and 3 a.m. This is because the automatic date-change mechanism is already in action between these times.

Never turn the hands anti-clockwise (except for small corrections of less than 1 hour).

JAEGER-LECOULTRE WATCHES

In order to benefit from the International Guarantee and/or the Limited Warranty and/or the Manufacturer's Guarantee for Australia, Jaeger-LeCoultre products must be purchased exclusively from authorised Jaeger-LeCoultre retailers or from Jaeger-LeCoultre Boutiques. Maintenance and repair work must be entrusted to an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre. If these conditions are not met, the manufacturer's guarantee does not apply. Please contact Jaeger-LeCoultre to obtain the list of authorised Jaeger-LeCoultre retailers across the world.

INTERNATIONAL GUARANTEE


The International Guarantee applies to Jaeger-LeCoultre products sold or presented for guarantee repairs in all countries, except the United States of America and Canada (for these two countries, see the Limited Warranty) and Australia (for this country, refer to the Guarantee for Australia).

TERMS AND CONDITIONS OF THE JAEGER-LECOULTRE INTERNATIONAL GUARANTEE

Your Jaeger-LeCoultre watch is guaranteed to protect against all manufacturing defects for two years from the date of purchase, subject to the following conditions. Any part found by our technical services to be defective as a result of a manufacturing defect will, at the sole discretion of Jaeger-LeCoultre, be repaired or replaced free of charge. The Jaeger-LeCoultre In-

ternational Guarantee is valid only if the guarantee certificate enclosed with this booklet has been duly completed, dated, stamped, and signed by the authorised Jaeger-LeCoultre retailer or the Jaeger-LeCoultre Boutique, which sold you your watch.

The Jaeger-LeCoultre International Guarantee does not cover defects resulting from accidents, mishandling, or incorrect, abusive use (for example, knocks, dents, crushing, excessive temperatures, powerful magnetic fields), the use of or effect of using batteries other than those designated by Jaeger-LeCoultre, unauthorised alteration or repair, the consequences of normal wear and ageing of the watch, strap, or glass, the loss of water resistance after two years from the date of purchase, if your watch is water-resistant, or any defect resulting from contact with water, if your watch is not water-resistant.

Jaeger-LeCoultre water-resistant watches can be identified by the symbol  and/or

by “3, 5, 10, or 20 bar” (or another number depending on the model) engraved on the caseback. Their water resistance is guaranteed for two years from the date of purchase, provided that the glass, bezel, back, middle part, and crown have not been damaged. It is nevertheless essential to have the water resistance of your watch checked at least once every two years, and in any event, prior to any period of intensive use, either by an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre (for further information please see your User Manual).

For quartz watches, this guarantee does not cover the battery life.

As a consumer, you may have legal rights under applicable national legislation governing the sale of consumer goods; those rights are not affected by this guarantee.

LIMITED WARRANTY (UNITED STATES OF AMERICA AND CANADA)


The following Limited Warranty applies to Jaeger-LeCoultre products sold or presented for warranty repairs in the United States of America and Canada only.

TERMS AND CONDITIONS OF THE JAEGER-LECOULTRE LIMITED WARRANTY

Your Jaeger-LeCoultre watch is guaranteed against all manufacturing defects for two years from the date of purchase, subject to the following conditions. Any part found by our technical services to be defective as a result of a manufacturing defect will, at the sole discretion of Jaeger-LeCoultre, be repaired or replaced free of charge. The Jaeger-LeCoultre Limited Warranty is valid only if the warranty certificate enclosed with this booklet has been duly

completed, dated, stamped, and signed by the authorised Jaeger-LeCoultre retailer or the Jaeger-LeCoultre Boutique, which sold you your watch.

This Jaeger-LeCoultre Limited Warranty does not cover defects resulting from accidents, mishandling, or incorrect, abusive use (for example, knocks, dents, crushing, excessive temperatures, powerful magnetic fields), the use of or effect of using batteries other than those designated by Jaeger-LeCoultre, unauthorised alteration or repair, the consequences of normal wear and ageing of the watch, strap, or glass, the loss of water resistance after two years from the date of purchase, if your watch is water-resistant, or any defect resulting from contact with water, if your watch is not water-resistant.

Jaeger-LeCoultre water-resistant watches can be identified by the symbol  and/or by “3, 5, 10, or 20 bar” (or another number depending on the model) engraved on the caseback. Their water resist-

ance is guaranteed for two years from the date of purchase, provided that the glass, bezel, back, middle part, and crown have not been damaged. It is nevertheless essential to have the water resistance of your watch checked at least once every two years, and in any event, prior to any period of intensive use, either by an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre (for further information please see your User Manual).

For quartz watches, this guarantee does not cover the battery life.

Except insofar as prohibited by applicable law, this Limited Warranty shall be the exclusive manufacturer warranty. Neither this Limited Warranty nor any other warranties, whether expressed or implied, including, but not limited to, any implied warranty of merchantability or of fitness for any particular purpose, shall extend

beyond the period of two years from the date of purchase.

The liability of Jaeger-LeCoultre is limited solely and exclusively to repair or replacement under the terms and conditions stated herein. Jaeger-LeCoultre shall not be liable, by virtue of this Limited Warranty or otherwise, for any loss or damage arising out of the use of or inability to use this watch nor for any incidental or consequential damages relating in any way to this watch.

Some States, Provinces, and Territories do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This Limited Warranty grants you specific legal rights, in addition to which you may have other legal rights that vary from one Country, State, Province, or Territory to another.

GUARANTEE FOR AUSTRALIA

This Guarantee for Australia applies to Jaeger-LeCoultre products purchased or presented for guarantee repairs in Australia only.

TERMS AND CONDITIONS OF THE JAEGER-LECOULTRE GUARANTEE FOR AUSTRALIA


Mandatory Statutory Rights. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced, if goods fail to be of acceptable quality and the failure does not amount to a major failure.

This Jaeger-LeCoultre Guarantee gives you additional rights and remedies under the Australian Consumer Law and

any other laws in relation to the goods. Every Jaeger-LeCoultre product is made and tested to meet the Jaeger-LeCoultre quality standards. Nevertheless, should your Jaeger-LeCoultre product prove defective, please contact the Jaeger-LeCoultre retailer or Jaeger-LeCoultre Boutique indicated on your guarantee certificate; only authorised Jaeger-LeCoultre retailers or Jaeger-LeCoultre Boutiques are entitled to provide a guarantee service as defined in this Jaeger-LeCoultre Guarantee. In order to benefit from this guarantee, you will be required to present this Jaeger-LeCoultre guarantee certificate duly completed, dated, stamped, and signed by an authorised Jaeger-LeCoultre retailer or a Jaeger-LeCoultre Boutique.

This Jaeger-LeCoultre Guarantee covers defects of materials or workmanship of your Jaeger-LeCoultre product. Subject to your Mandatory Statutory Rights under the Australian Consumer Law,

Jaeger-LeCoultre will remedy these identified defects free of charge for up to two (2) years from the date of purchase. Thereafter, Jaeger-LeCoultre will repair any defective product or part subject to a service charge. The Jaeger-LeCoultre Guarantee does not cover defects and damage caused by accident, improper use (including knocks, dents, crushing, etc.), normal wear and tear, alteration, dismantling, repair by persons other than authorised Jaeger-LeCoultre repair specialists, the use of components other than those recommended by Jaeger-LeCoultre, watches with the serial number removed, the strap or glass altered, the loss of water resistance after two years from the date of purchase, if your watch is water-resistant, and any defect resulting from the contact with water, if your watch is not water-resistant.

Jaeger-LeCoultre water-resistant watches can be identified by the  symbol and/or by “3, 5, 10, or 20 bar” (or another number depending on the model) en-

graved on the caseback. Their water resistance is guaranteed for two years from the date of purchase, provided that the glass, bezel, back, middle part, and crown have not been damaged. It is essential to have the water resistance checked by an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre at least every two years, and in any event, prior to any period of intensive use. Please refer to the operating instructions for further details. For quartz watches, this guarantee does not cover the battery life.

Subject to your Mandatory Statutory Rights under the Australian Consumer Law, if you make a claim under this Jaeger-LeCoultre Guarantee (instead of your Mandatory Statutory Rights) you may be responsible for transportation costs, including but not limited to postage, insurance and packing materials.

In Australia, a claim under the Jaeger-LeCoultre Guarantee may be sent to Richemont Australia Pty Ltd, provider of the guarantee service, at the address below or as specified above:

Richemont Australia Pty Ltd

PO Box 4780

Sydney, NSW 2001

Tel: +1 800 71 0665

Email: client.relations.asia@jaeger-lecoultre.com

CUSTOMER SERVICE

A Jaeger-LeCoultre timepiece is a high-precision instrument that operates 24 hours a day, or 8,760 hours a year. Therefore, it is essential to have it serviced regularly in order to guarantee its good working order and its durability. If significant variations occur in the settings, it may be necessary to have the movement serviced. It is also necessary to have the water resistance of the watch checked once every two years, or prior to any period during which it will be subjected to prolonged and/or regular immersion.

Maintenance and repair work must be entrusted to an authorised Jaeger-LeCoultre retailer, a Jaeger-LeCoultre Boutique, or an authorised Jaeger-LeCoultre Service Centre. The list of our points of sale and service centres is available on our website: www.jaeger-lecoultre.com. You will also find this information at the end of this

document, under the heading “Where to entrust my timepiece for maintenance?”

Our authorised Service Centres are staffed by watchmakers trained at the Jaeger-LeCoultre Manufacture, and have the workshops, tools, and parts required for the repair and maintenance of Jaeger-LeCoultre watches and clocks.

In certain cases, especially for operations requiring special tools and parts, the Service Centres will send your watch to the Jaeger-LeCoultre Manufacture in Switzerland to have the necessary work carried out.